

## X-Cite® 110LED Control Options

### Control Options

Manual Control – speedDIAL	ON/OFF Speed sensitive intensity control 1 favorite intensity setting Left and right-handed control option
USB	ON/OFF Intensity control Compatible with X-Cite 120PC, X-Cite exacte, X-Cite 120LED and X-Cite 110LED drivers
TTL	ON/OFF